

Front brake and clutch master cylinder banjo bolts Check torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Front circuit manifold banjo bolt (12 mm) Check Torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Front caliper banjo bolts Check Torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Rear master cylinder banjo bolt Check Torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Rear caliper banjo bolt Check Torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Rear circuit manifold banjo bolt (10 mm) Check Torque 1 , 5 , 6	✓		✓		✓		✓		✓		✓
Brake and clutch controls Check, adjust and lubricate with HARLEY LUBE 5	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Parking brake Inspect and adjust 5	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Rear tires Check pressure, inspect tread 1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Drive belt and sprockets Inspect, adjust belt 5	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Rear sprocket isolators Inspect for wear 5					✓				✓		
Rear lug nuts Check torque 1 , 5 , 6 , 11	✓		✓		✓		✓		✓		✓
Rear fork Check pivot shaft nut torque 1 , 5 , 10	✓		✓		✓		✓		✓		✓
Air suspension Check pressure, operation and leakage 1 , 5 , 9	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Exhaust system Inspect for leaks, cracks, and loose or missing fasteners or exhaust shields 1 , 9	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Battery Check battery and clean connections annually. Battery terminal torque 1	Check annually										
Clean and lubricate terminals with ELECTRICAL CONTACT LUBRICANT 1	Perform annually										
Spark plugs	Replace every two years or every 30,000 mi (48,000 km), whichever comes first.										
Fuel door Lubricate hinge and latch with HARLEY LUBE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Front forks Rebuild 5 , 12											✓
Fuel filter element 5	Replace every 100,000 mi (160,000 km).										
Road test Verify component and system functions 13	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

NOTES

1. Perform annually or at specified intervals, whichever comes first.
2. Replace DOT 4 hydraulic fluid and flush system every two years.
3. Brake fluid level will drop as brake pads wear.
4. Clutch fluid level will rise as clutch wears.
5. Should be performed by an authorized Harley-Davidson dealer, unless you have the proper tools, service data and are mechanically qualified.
6. Attempt to turn the fastener using a torque wrench set to the minimum torque specification for that fastener. If the fastener does not rotate, the fastener torque has been maintained. No further attention is necessary. If fastener moves, tighten to specification.
7. Disassemble, inspect, lubricate and adjust every 25,000 mi (40,000 km).
8. Replace or have rebuilt at 50,000 mi (80,000 km).
9. Perform maintenance more frequently in severe riding conditions such as extreme temperatures, dusty environments, mountainous or rough roads, long storage conditions, short runs, heavy stop/go traffic or poor fuel quality.
10. Attempt to turn the fastener using a torque wrench set to the minimum torque specification for that fastener. If the fastener does not rotate, the fastener torque has been maintained. No further attention is necessary. If the fastener moves, clean all locking material from the threaded hole. Replace the fastener with a new one or clean the original fastener threads and apply the appropriate locking agent

(see appropriate procedure). Install fastener. Tighten to specification.

11. Always check lug nut torque within 500-1000 mi (805-1610 km) after wheel installation.
12. Disassemble, inspect, rebuild forks and replace fork oil every 50,000 mi (80,000 km).
13. Check reverse operation at each service interval.