

FRONT HOLES TO TOP SHOUL MOUNT = $2\frac{1}{2}$ "
 TOP SHOCK MOUNT TO 2ND HOLES = 4"
 S102 TO S103 (W102A) = $10\frac{3}{8}$ "

FRONT

