



Figure 5-1K. 1978 FL/FLH 1200 Wiring Diagram

## 1978 FX/FXE 1200 WIRING DIAGRAM KEY

1. Headlamp housing
2. Socket-plug combination
3. Socket-plug combination
4. Socket-plug combination
5. Wiring harness
6. Headlamp beam switch
7. Horn switch
8. Ignition breaker (timer)
9. Wire connector
10. Battery positive terminal
11. Battery negative terminal
12. Frame lug bolt
13. Stop lamp switch — rear
14. Switch "ST" lights terminal
15. Switch "G" ignition terminal
16. Switch "B" battery terminal
17. Regulator — rectifier module
18. Alternator to module connector plug
19. Alternator stator
20. Horn
21. Headlamp socket
22. Engine stop switch
23. Stop lamp switch — front
24. Ignition coil
25. Main circuit breaker
26. Rear turn signal connector
27. Tail lamp connector
28. Long stud on starter solenoid
29. Speedometer light
30. Oil pressure signal switch
31. Neutral switch
32. Neutral indicator light
33. Oil signal lamp
34. High beam indicator lamp
35. Tail and stop lamp
36. Tachometer
39. Lighting circuit breaker
40. Ignition circuit breaker
41. Accessories circuit breaker
42. Starter switch
43. Right turn signal switch
44. Left turn signal switch
45. Turn signal flasher
46. Left front turn signal lamp
47. Right front turn signal lamp
48. Left rear turn signal lamp
49. Right rear turn signal lamp
50. Starter relay (FXE only)
51. Starter solenoid (FXE only)
52. Starter motor (FXE only)
53. Violet tag
54. Brown tag